



Lighting Options

Troubleshooting

Your system may be equipped with optional overhead lights. Use of these lights usually requires no effort on your part. The lights will come on when the aisle is opened or when an aisle is entered. The lights will shut off automatically shortly after you leave the aisle.

If the lights do not turn on when an open aisle is entered, simply press the "Move" button on the controls on either side of the aisle.

If the lights are not timed to turn off automatically after leaving the aisle, they can be turned off by pressing the "Stop/Reset" button on the controls on either side of the aisle.

CONTROL INDICATION	SOLUTION
Abnormal Carriage Movement	<ul style="list-style-type: none">• Check rails for debris; clean rails
Controls on both sides of the open aisle display "Aisle in Use" and the LED is flashing red	<ul style="list-style-type: none">• Check the aisle for people or materials obstructing safeties• Press the "Stop/Reset" button• If there is no apparent obstruction, check the LED on one end of the Photo Sweep. If the LED is not flashing green, call for service. <i>(The safety override key may be used in the interim – see the Safety section of this manual)</i>
None of the controls work; None of the LED's are lit	<ul style="list-style-type: none">• Is the system locked (via remote, key, etc.)?• Is power supplied to the system? In the event of a power outage, use your power outage option (if purchased).• Call Service
All or most controls display a blinking red LED	<ul style="list-style-type: none">• Call Service

Rails

- Vacuum the rails and track regularly.
- Some flaking may be seen on the rail surface. This is normal and no cause for alarm. A light application of a silicon or teflon spray to the top of the rail is recommended to reduce this type of wear. Avoid sweeping or mopping over freshly lubricated rails.

Controls

- Check all the functions of every control.

Carriage Bumpers and End Stops

- Please notify your local Spacesaver service technician if you observe any missing or damaged bumpers and/or stops.

Stored Media

- All materials must be pushed onto the shelves and be flush with the shelf front. Any media overhanging the shelf front will interfere with normal system operation. This media is very likely to become damaged by normal system operation as well. Looking for evidence of media interference can help identify potential problems.

Laminate Panels

- To clean and restore the surface apply a countertop or laminate cleaner (found at most hardware stores.)

Metal Surfaces

- All metal surfaces are painted with the powder coat system. This is a high luster and scratch resistant paint.
- To remove surface dust, wipe with a damp cloth.
- To clean soiled surfaces, wash with a mild soap and water mixture.
- To remove finger prints, an orange-based cleaner or NON-ammonia window cleaner will work on some colors. Test a small area before using it on a large surface.

Miscellaneous

- Move the carriage in both directions. Look, listen, and feel for smooth travel. Please inform your local Spacesaver service technician of any unusual sounds or vibrations.
- All carriages should move easily across the aisle in both directions.
- Make sure the floor covering does not interfere with carriage movement or function.
- All carriages should track properly across the aisle. If one end of the carriage lags behind, please inform your local Spacesaver service technician.

General Maintenance